
	<p><b>Bridgeworks Limited</b> Department: Support</p>	<p><b>Release</b></p>
<p><b>Firmware Release Notes</b></p>		
<p>Firmware Version <b>v3.04.08</b></p>	<p>Release date: <b>April 2014</b></p>	



## Firmware Release Notes

Version: v3.04.08


	<p align="center"><b>Bridgeworks Limited</b> Department: Support</p>	<p align="center"><b>Release</b></p>
<p><b>Firmware Release Notes</b></p>		
Firmware Version <b>v3.04.08</b>	Release date: <b>April 2014</b>	

## Warning

---

Bridgeworks Ltd. provides this product “as is” without warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability or fitness for purpose. In no event shall Bridgeworks Ltd. be liable for any consequential, direct, exemplary, incidental, indirect or special damages, or any other loss including but not limited to loss of profits, loss of business, loss of use of data.

Information supplied in this document is believed to be accurate and reliable at the time of creation. However, Bridgeworks Ltd. assumes no responsibility for its use. Bridgeworks Ltd. reserves the right to change the contents of this document without notice.

	<p align="center"><b>Bridgeworks Limited</b> Department: Support</p>	<p align="center"><b>Release</b></p>
<p><b>Firmware Release Notes</b></p>		
Firmware Version <b>v3.04.08</b>	Release date: <b>April 2014</b>	

## Contents

1	Introduction.....	4
2	Requirements .....	4
3	Overview.....	4
4	Features .....	4
5	Enhancements.....	4
6	Resolved Issues.....	4
7	Known Issues .....	5
8	Upgrading the Firmware.....	5

	<b>Bridgeworks Limited</b> Department: Support	<b>Release</b>
<b>Firmware Release Notes</b>		
Firmware Version <b>v3.04.08</b>	Release date: <b>April 2014</b>	

## 1 Introduction

This document accompanies each and every release of this product firmware. It describes:

- Which version it replaces.
- Added features since the previous release.
- Feature Enhancements
- The errors and omissions fixed from the previous release.
- Known errors at the release date.
- Instructions on how to update your firmware

## 2 Requirements

This version of the v3.04 firmware is only intended for the following products;- Rialto SE1100. Updates for other products will be released shortly.

**If you are in any doubt, contact the Support Desk.**

## 3 Overview

This release replaces the v3.02 series of releases, the last release excluding maintenance releases being v3.02.03.

## 4 Features

Instructions on how to use the new features can be found in the latest user manual for your product, available from [www.4bridgeworks.com](http://www.4bridgeworks.com)

- IPv6 Support Added
- SNMP Support Added

## 5 Enhancements

The following feature enhancements have been made in this release:

- GUI notification that the user will logout if they remain idle
- Reboot page detects when the unit has booted and will redirect to the login page
- Network interfaces page re-styled for IPv6 configuration options
- A warning message is now displayed when adding a SCSI target to ID 7
- A warning message is now displayed when adding non-contiguous luns

## 6 Resolved Issues

The following resolved issues are included in this release:

- NTP failure when receiving duplicate or fraudulent responses
- The user is able to set an IP address in the form 0.x.x.x
- The default gateway is no longer a mandatory field
- Reboot operations would hang occasionally before reboot.
- LANScan now response to all requests, previous routing error prevented response
- The GUI times out when rebooting the unit.
- The manager crashes during vulnerability testing.

	<b>Bridgeworks Limited</b> Department: Support	<b>Release</b>
<b>Firmware Release Notes</b>		
Firmware Version <b>v3.04.08</b>	Release date: <b>April 2014</b>	

## 7 Known Issues

There are currently no known issues in this release.

## 8 Upgrading the Firmware

1. Connect to the Manager using your web browser.
2. Log in using the usual password
3. Select the load/save configuration icon
4. Under Export configuration, click on the button that says "Click here to download"
5. Confirm the download of your configuration
6. Click on the "Home" link in the left hand window
7. Select the 'Firmware Update' option
8. Click the browse button and select the '.system' file that you received.
9. Once the filename is in the text box click on the 'Update' button below.
10. If you are updating from a v3.1 series or newer firmware, please wait for the blue progress bar to complete.
11. The web interface will then inform you that the update is complete and that the board should be rebooted.



**Note:** More details on how to perform a firmware update are available in your devices product manual.